




# Wrap Spring Clutches – Replacement Parts

## DCB-8 & DCB-8 SUPER Metric Replacement Parts



Item	Part No.	Rotation or Voltage	Description
1	D748-1-0039		Retaining Ring
2	D540-8-0041 D541-8-0012		Metric Input Hub Super - Metric Input Hub
3	D266-8-0001 D266-8-0002 D266-8-0004 D266-8-0153 D266-8-0154 D266-8-0156 D266-8-0031 D266-8-0032 D266-8-0034 D266-8-0157 D266-8-0158 D266-8-0160	CW CW CW CW CW CW CCW CCW CCW CCW CCW CCW	1 Stop Collar 2 Stop Collar 4 Stop Collar Super - 1 Stop Collar Super - 2 Stop Collar Super - 4 Stop Collar 1 Stop Collar 2 Stop Collar 4 Stop Collar Super - 1 Stop Collar Super - 2 Stop Collar Super - 4 Stop Collar
4	D808-8-0003 D808-8-0004	CW CCW	Clutch Spring Clutch Spring
5	D808-8-0025 D808-8-0026	CW CCW	Anti-Overrun Spring Anti-Overrun Spring
6	D824-8-0420 D824-8-0410 D824-8-0589 104745	35mm 40mm 35mm 40mm	Output Shaft Output Shaft Super - Output Shaft Super - Output Shaft
7	D808-8-0025 D808-8-0026	CW CCW	Anti-Back Spring Anti-Back Spring
8	D808-8-0003 D808-8-0004	CW CCW	Brake Spring Brake Spring
9	D540-8-0016 D541-8-0010		Brake Hub Super - Brake Hub
10	D686-8-0051 D686-8-0052	CW CCW	Plate Assembly Plate Assembly
11	D102-1-0004 D102-1-0021		Actuator Assembly D6 Coil Actuator Assembly D7 Coil
12	D816-1-0005		* Actuator Limit Stop
13	DY-10714		Socket Head Screw
14	D950-1-0052		* Flat Washer
15	D950-1-0019		* Lock Washer
16	D797-1-0035		* Socket Head Screw
17	D101-1-0028 D101-1-0053	24VDC 24VDC	Coil Assembly D6 Super - Coil Assembly D7
18	D797-1-0174		M-6 Set Screw
19	D950-8-0001		Super - Thrust Washer