

## Electromagnetic Power-On Friction Clutches

*(For Imperial Units)*

A			A			B		B - C		D		E		F	
DIGIT	DIGIT	MODEL NO.	DIGIT	DIGIT	SIZE	DIGIT	VOLTS	DIGIT	BORE (INCH)	DIGIT	DRIVE	DIGIT	CONNECTION		
0	1	SL	0	9	08	1	90 VDC	1	1/8	1	ZERO BACKLASH	1	LEAD WIRES		
0	3	BSL	1	0	11	2	24 VDC	2	3/16			2	SCREW TERMINALS		
0	5	FL	1	1	15	3	12 VDC	3	1/4						
0	7	SO	1	2	17	4	120 VAC	4	5/16						
0	9	FO	1	3	19			5	3/8						
1	1	FB	1	4	22			6	1/2						
1	3	SLB	1	5	26			7	5/8						
1	5	SOB	1	6	30			8	3/4						
			1	7	42			9	7/8						
								0	1						

### How To Order

- A.** Select the model number from the product guide.
- B.** Select the size of the clutch or brake.
- C.** Select the voltage.
- D.** Select the bore diameter.
- E.** For all power-on clutches and brakes, select 1.
- F.** For all clutches and brakes, refer to the product guide and specify 1 or 2.

### Example (Imperial)

SL11 clutch, 24 volts, 1/4 bore  
Part No. 0110-2311

*(For Metric Units)*

M			A			A		B		B - C		D		E		F	
DIGIT	DIGIT	MODEL NO.	DIGIT	DIGIT	SIZE	DIGIT	VOLTS	DIGIT	BORE (MM)	DIGIT	DRIVE	DIGIT	CONNECTION				
0	1	SL	0	9	08	1	90 VDC	1	5	1	ZERO BACKLASH	1	LEAD WIRES				
0	5	FL	1	0	11	2	24 VDC	2	6			2	SCREW TERMINALS				
0	7	SO	1	1	15	3	12 VDC	3	8								
0	9	FO	1	2	17	4	120 VAC	4	10								
1	1	FB	1	3	19			5									
			1	4	22			6	15								
			1	5	26			7	17								
			1	6	30			8	20								
			1	7	42			9	25								